




# PFR Pump FVP Custom Ground 7mm Lift Cam Installation Instructions

For correct installation and clearance, the pump must have the correct shim between the pump housing and the cambox housing. Using a depth micrometer, with shim installed, measure the distance from the pump mounting surface to the base circle of the camshaft lobe. This measurement must be between 2.635" and 2.645". If the clearance is less than 2.635", it may result in pump damage. If the clearance is greater than 2.645", it will result in a lower fuel flow amount.



0105

